


Card Printer Quick Install Guide



Do not continue unpacking this box until you have read these instructions to set up your Sigma printer.




1




- 1 Printer
- 2 USB cable
- 3 Power cord
- 4 Power supply

2


Refer to your ribbon supply box (not included) to prepare the ribbon.



3



4




5



If you plan to have a USB connection with the printer, do not plug in the USB cable until directed by the driver.



If you plan to have a network connection with the printer, plug in the Ethernet cable, then press the User button for three seconds to print a test card with printers IP address and auth ID key.



Documentation and driver software is available on the USB drive provided with the printer.



- User's Guide
- Installation and Administrator's Guide
- User's Reference Guide
- Warranty
- Driver

WARNING: This product contains chemicals, including lead, known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling.

WARNING: This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP), which is known to the State of California to cause cancer, and Di(2-ethylhexyl)phthalate (DEHP) and Butyl benzyl phthalate (BBP), which are known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.