

Retrieve the Printer IP Address


Use the printer LCD panel to retrieve the printer's IP address. When the LCD displays **Ready**, press the down arrow until the IP address displays and record the address.

SD, CD, CE-Series and CR805 Retransfer Card Printers:



Sigma Card Printers:

The LCD panel also displays a QR code that you can use to start the Printer Dashboard to see additional printer information and work with the printer.



Refer to the printer's *User's Guide* for complete information about how to retrieve the IP address.



The Card Printer Driver supports both IPv4 and IPv6 addresses for network-connected printers. Refer to your printer's *User's Guide* for complete information about obtaining an IPv6 address.